```
RIP (ROUTING INFORMATION PROTOCOL)
Router a bağlı networkleri yazıyoruz. (router ın bildiği, directly connected, Show ip route C çıkan)
```

Router(config) #router rip Router(config-router) #network <Network ID>

```
R1(config) #router rip
R1(config-router) #network 192.168.5.0
R1(config-router) #network 172.16.1.0
```

Ripv2 de alt ağ maskesi de girilir R1(config)#router rip R1(config)# version 2 R1(config-router)#network 192.168.5.0 255.255.255.0

OSPF (OPEN SHORTEST PATH FIRST)

Router(config) #router ospf <OSPF Process number>
Router(config-router) #network <Network ID> <Wild Card Mask> area <Area
number>

Wildcard mask alt ağ maskesinin tersi (255.0.0.0 0.255.255.255 şeklinde bir wildcard mask a sahiptir)

R1(config)#router ospf 1
R1(config-router)#network 10.0.0.0 0.255.255.255 area 0
R1(config-router)#network 20.0.0.0 0.255.255.255 area 0

DHCP

Router(config)#ip dhcp pool mypool //pool'a bir isim verdik

Router(dhcp-config)#network 192.168.1.0 255.255.255.0 //IP dağıtılacak network

Router(dhcp-config)#default-router 192.168.1.1 // gateway IP

Router(config)#ip dhcp excluded-address 192.168.1.1 192.168.1.10 //dağıtılmayacak IP aralığı

Router# show ip dhcp binding //DHCP ile dağıtılan IP'lere bakma